




Vastaanotin / Mottagaren / Receiver




Kytkin / Brytaren / Switch



1 kanava/kanal/channel




2 kanavaa/kanaler/channels



Kyttimeen seinäasennus / Vägmontering av strömbrytare / Switch Wall Mounting


Paritus / Parkoppling / Linking



Työnnä vastaanotin pistorasiaan.

Sätt mottagaren i vägguttaget.

Plug the receiver into the socket.



Paina ON-kytintä lyhyesti.

Tryck kort på ON-knappen.

Briefly press the ON button.




Linkitys on valmis, kun vastaanotin naksahtaa 4 kertaa.

Parkopplingen är färdig när mottagaren klickar 4 gånger.

Pairing is complete when the receiver clicks 4 times.


Parituksen poisto / Avparkoppling / Unlinking



Irrota vastaanotin pistorasiasta ja työnnä takaisin.

Dra ut mottagaren ur vägguttaget och sätt tillbaka den.

Unplug the receiver and plug it back in.



Paina 6 sekunnin sisällä OFF-kytintä lyhyesti.

Tryck kort på OFF-knappen inom 6 sekunder.

Briefly press the OFF button within 6 seconds.



Linkitys on poistettu, kun vastaanotin naksahtaa 4 kertaa.

Parkopplingen har tagits bort när mottagaren klickar 4 gånger.

The pairing is unlinked when the receiver clicks 4 times.



Model	91422142, 91422143
	91422130 + 121931, 121933

Maximum load	2300 Watt
Power	220-240VAC 50Hz
RF	433,92 MHz